

BONDINE® HX8210

Ethylene – Acrylic Ester - Maleic Anhydride terpolymer

DESCRIPTION

BONDINE® 8210 is a random terpolymer of ethylene, acrylic ester and maleic anhydride, polymerized by high-pressure autoclave process.

TYPICAL PROPERTIES

Characteristics	Value	Unit	Test Method
Ethyl Acrylate content	6.5	% Wt	FTIR (internal method)
Maleic Anhydride content	2.8	% Wt	FTIR (internal method)
Melt Index (190°C / 2.16 kg)	200	g/10min	ISO 1133 / ASTM D1238
Melting point	100	°C	ISO 11357-3
Density	0.94	g/cm ³	ISO 1183 / ASTM D1505
Vicat softening temperature (10N) ⁽¹⁾	57	°C	ISO 306 / ASTM D1525
Flexural modulus ⁽¹⁾	40	MPa	ISO 178 / ASTM D790
Elongation at break ⁽¹⁾	400	%	ISO 527-2 / ASTM D638
Tensile strength at break ⁽¹⁾	6	MPa	ISO 527-2 / ASTM D638
Hardness Shore D ⁽¹⁾	26		ISO 868 / ASTM D2240

⁽¹⁾ On compression molded samples.

APPLICATIONS

Due to its properties, reactivity, fluidity and compatibility with tackifying resins and waxes, **BONDINE® 8210** is suitable as additive for hot melt adhesive formulations and as coupling agent in mineral filled compounds.

For more detailed information and recommendations regarding your specific application, please contact your local ARKEMA technical representative.

BONDINE® HX8210

PROCESSING

Standard polyolefin extrusion equipment can be used for **BONDINE® 8210**, which has the same processability as LDPE and the same heat stability given by acrylate comonomers. Recommended temperature range is from 270°C up to 320 – 330°C. It is recommended to purge the equipment with LDPE after a run is completed before shutting down.

STORAGE, HANDLING AND SAFETY

BONDINE® 8210 is usually packed in waterproof bags or rigid containers with waterproof liner. It should be stored in dry conditions and be kept out of moisture in an aerated building. Improper storage conditions may cause degradation and could have consequences on physical properties of the product. It is recommended to reseal the bag or the liner after use to protect **BONDINE® 8210** against moisture.

Safety data sheet as well as information on handling and storage of the **BONDINE® 8210** is available upon request to your ARKEMA representative or on the web site BONDINE.com.

SHELF LIFE

Two years from the date of delivery, in unopened packaging. For any use above this limit, please refer to our technical services.

April 2014

The products described in the brochure are not Medical grades designated for Medical Device applications. Arkema has implemented an internal Medical Policy regarding the use of Arkema products in Medical Devices applications that are in contact with the body or circulating bodily fluids. Arkema has designated Medical grades to be used for such Medical Device applications. Products that have not been designated as Medical grades are not authorized by Arkema for use in Medical Device applications that are in contact with the body or circulating bodily fluids. In addition, except for limited cases as determined by the Medical Device Policy, Arkema strictly prohibits the use of any Arkema products in Medical Device applications that are implanted in the body or in contact with bodily fluids or tissues for greater than 30 days.

The statements, technical information and recommendations contained herein are believed to be accurate as of the date hereof. Since the conditions and methods of use of the product and of the information referred to herein are beyond our control, ARKEMA expressly disclaims any and all liability as to any results obtained or arising from any use of the product or reliance on such information; NO WARRANTY OF FITNESS FOR ANY PARTICULAR PURPOSE, WARRANTY OF MERCHANTABILITY OR ANY OTHER WARRANTY, EXPRESS OR IMPLIED, IS MADE CONCERNING THE GOODS DESCRIBED OR THE INFORMATION PROVIDED HEREIN. The information provided herein relates only to the specific product designated and may not be applicable when such product is used in combination with other materials or in any process. The user should thoroughly test any application before commercialization. Nothing contained herein constitutes a license to practice under any patent and it should not be construed as an inducement to infringe any patent and the user is advised to take appropriate steps to be sure that any proposed use of the product will not result in patent infringement.

See MSDS for Health & Safety Considerations.

Arkema Functional Polyolefins
420, rue d'Estienne d'Orves
92705 Colombes Cedex - France
arkema.com – lotader.com

ARKEMA
INNOVATIVE CHEMISTRY

ARKEMA Société anonyme au capital de 614 937 940 euros - 445 074 685 RCS Nanterre