

OREVAC[®] 18910

Linear low-density tie resin for film or sheet coextrusion

DESCRIPTION

OREVAC[®] 18910 is a maleic anhydride modified linear low-density polyethylene available in pellet form. It can be processed on most extrusion equipments designed to process conventional polyolefins.

TYPICAL PROPERTIES

Characteristics	Value	Unit	Test Method
Melt Index (190°C / 2.16 kg)	1.5	g/10min	ISO 1133 / ASTM D1238
Melting point	117	°C	ISO 11357-3
Density	0.950	g/cm ³	ISO 1183 / ASTM D1505
Vicat softening temperature (10N) ⁽¹⁾	77	°C	ISO 306 / ASTM D1525

⁽¹⁾ On compression molded samples.

APPLICATIONS

OREVAC[®] 18910 has been designed to develop a reliable bonding strength between PS, PE, EVOH and PA in coextruded multi-layer structures like films or sheets.

For more detailed information and recommendations regarding your specific application, please contact your local ARKEMA technical representative.

OREVAC® 18910

PROCESSING

OREVAC® 18910 is to be processed like a standard polyethylene resin.

Extrusion temperature settings could be:

Zone 1	Zone 2	Zone 3	Zone 4	Exit	Fittings-Channels	Die
190 - 200°C	200 - 200°C	200 - 210°C	210 - 220°C	220 - 230°C	220 - 240°C	220 - 240°C

Final profile and settings depend on the line and the multi-layer structure being run.

We recommend not to reach melt temperature above 250°C. Too high processing temperature could lead to degradation of OREVAC®.

STORAGE, HANDLING AND SAFETY

OREVAC® 18910 should be stored in dry conditions protected from UV-light. Improper storage conditions may cause degradation and have consequences on physical properties of the product.

Safety data sheet as well as information on handling and storage of OREVAC® 18910 is available upon request to your ARKEMA representative or on the web site orevac.com.

SHELF LIFE

Two years from the date of delivery, in unopened packaging. For any use above this limit, please refer to our technical services.

April 2014

The products described in the brochure are not Medical grades designated for Medical Device applications. Arkema has implemented an internal Medical Policy regarding the use of Arkema products in Medical Devices applications that are in contact with the body or circulating bodily fluids. Arkema has designated Medical grades to be used for such Medical Device applications. Products that have not been designated as Medical grades are not authorized by Arkema for use in Medical Device applications that are in contact with the body or circulating bodily fluids. In addition, except for limited cases as determined by the Medical Device Policy, Arkema strictly prohibits the use of any Arkema products in Medical Device applications that are implanted in the body or in contact with bodily fluids or tissues for greater than 30 days.

For any use of Arkema's product in Medical Device applications, please contact Arkema's sales network.

The statements, technical information and recommendations contained herein are believed to be accurate as of the date hereof. Since the conditions and methods of use of the product and of the information referred to herein are beyond our control, ARKEMA expressly disclaims any and all liability as to any results obtained or arising from any use of the product or reliance on such information; NO WARRANTY OF FITNESS FOR ANY PARTICULAR PURPOSE, WARRANTY OF MERCHANTABILITY OR ANY OTHER WARRANTY, EXPRESS OR IMPLIED, IS MADE CONCERNING THE GOODS DESCRIBED OR THE INFORMATION PROVIDED HEREIN. The information provided herein relates only to the specific product designated and may not be applicable when such product is used in combination with other materials or in any process. The user should thoroughly test any application before commercialization. Nothing contained herein constitutes a license to practice under any patent and it should not be construed as an inducement to infringe any patent and the user is advised to take appropriate steps to be sure that any proposed use of the product will not result in patent infringement.

See MSDS for Health & Safety Considerations.

Arkema Functional Polyolefins
420, rue d'Estienne d'Orves
92705 Colombes Cedex - France
arkema.com — orevac.com

ARKEMA
INNOVATIVE CHEMISTRY